

## REMOTE BATTERY STATEMENT

- Use type CR2025 batteries.
- Do not mix old and new batteries.
- Install only new batteries of the same type in your product.
- Do not mix Alkaline, Standard (Carbon-Zinc) or Rechargeable (Nickel Cadmium) or (Nickel Metal Hydride) batteries.
- Failure to insert batteries in the correct polarity, as indicated in the battery compartment, may shorten the life of the batteries or cause batteries to leak.
- Danger of explosion if battery is incorrectly inserted or replaced.

## FCC STATEMENT OF COMPLIANCE

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules and Industry Canada ICES-003. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by

turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: This device complies with part 15 of the FCC rules and Industry Canada ICES-003. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## HAVE A PROBLEM? PLEASE CONTACT CUSTOMER SERVICE.

Should you have any questions or comments please contact us at: [customerservice@blackstoneltd.com](mailto:customerservice@blackstoneltd.com)  
**1-888-525-7969**

**WARRANTY:** This heater includes a one (1) year warranty, which covers manufacturer defects and workmanship under normal use. A warranty is offered only to the original purchaser. Proof of purchase is required. Proof of purchase constitutes a dated sales receipt. This warranty is void if the heater(s) have been subject to improper use such as: abuse, being dropped which could result in damage to the heater cabinets, motors, heater controls, etc. immersion in or exposure to water, exposure to excessive heat, outdoor usage, any use other than household use, disassembly, repair or alteration by anyone other than an authorized service provider, use on improper voltage or current, or any use contrary to the user instructions.

Batteries and battery life are not covered in this warranty. No other warranties are expressed or implied are provided. To receive coverage under this warranty, contact customer service for consultation and/or replacement. DO NOT attempt to repair any electrical or mechanical functions of this product; doing so will void this warranty and could lead to injury.

### MADE IN CHINA

Distributed by: Blackstone International, LTD.  
2018 Lord Baltimore Drive  
Windsor Mill, MD 21244  
USA




BLACKSTONE®

# CASCADE PRO

## 13-INCH PERSONAL HEATER INSTRUCTION MANUAL

MODEL: CPPH-23-B,  
CPPH-23-S  
VOLTAGE: 120V AC  
FREQUENCY: 60Hz  
CURRENT: 0.4A



**IMPORTANT, RETAIN FOR FUTURE REFERENCE:  
READ CAREFULLY | FOR HOUSEHOLD USE ONLY  
Use Only With a Fuse Rated 2.5 Amperes, 125 Volts**


**This product contains a button battery. Do not swallow. If swallowed, it could cause severe injury or death in just 2 hours. Seek medical attention immediately.**

Blackstone International Ltd. and other trademarks are the property of the respective owners. All other brand names and logos are registered trademarks of their respective owners.

**PLEASE READ AND SAVE THESE INSTRUCTIONS WHEN USING ELECTRICAL APPLIANCES, BASIC PRECAUTIONS SHOULD ALWAYS BE FOLLOWED TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK AND INJURY TO PERSON OR PROPERTY, INCLUDING THE FOLLOWING:**

- Read all instructions before using this heater.
- This heater is hot when in use, and for a time after. To avoid burns, do not let bare skin touch hot surfaces. If provided, use handles when moving this heater.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9m) from the front of the heater and keep them away from the sides and rear.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Always unplug heater when not in use.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner.
- Discard heater, or return to authorized service facility for examination and/or repair.
- Do not use outdoors.
- This heater is not intended for use in bathrooms, laundry areas and similar indoor locations. Never locate heater near a water source.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect heater, turn controls to off, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any portion of the heater as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces like a bed, where openings may become blocked or heater may fall.
- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored. Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- Always plug heater directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- This heater may include an audible (a visual alarm to warn that parts of the heater are getting excessively hot. If the alarm sounds (flashes), immediately turn the heater off and inspect for any objects on or adjacent to the heater that may cause high temperatures. **DO NOT OPERATE THE HEATER WITH THE ALARM SOUNDING (FLASHING).**
- Hyperthermia can result in death. Symptoms of hyperthermia include high body temperature, headache, nausea, vomiting, tiredness, dizziness, fainting, and rapid pulse. If you begin to experience symptoms related to hyperthermia, turn off the heater and seek medical attention.
- To avoid excessive room temperatures which can cause hyperthermia: **DO NOT** leave product running unattended in a confined space around infants, or individuals with reduced physical, sensory, or mental capabilities.

Note: To reduce the risk of fire, electrical shock and injury to a person or property, do not plug this product into extension cords. The extension cord could overheat. If the use of an extension cord is necessary, use a short extension cord that is UL or ETL listed to decrease the chance of overheating. Do not plug the fan into any cord connected devices. This includes surge protectors, multiple outlet adapters, and power strips.



POWER Turns Heater On/Off



OSCILLATE Turns oscillation On/Off

SPEED SELECTION  
Appears on digital display



F	H1	H2
Fan only mode	Heat setting 1: 500 watts	Heat setting 2: 1050 watts

AUTO The heat setting will be automatically adjusted according to the ambient room temperature. The gear will decrease to "H1" when room temperature is more than 77°F, and will decrease to "F" when when room temperature is more than 86°F.

**AUTO**



TIMER Allows for automatic shutoff. Time increases by 1 hour with each push of the button. The LED indicators are cumulative to a maximum of 15 hours.



LED HEATER LIGHT Turns heater lights on/off



**WARNING: Chemical Burn Hazard.** Keep batteries away from children. This product contains a lithium button/coin cell battery. If a new or used lithium button/coin cell battery is swallowed or enters the body, it can cause severe internal burns and can lead to death in as little as 2 hours. Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep it away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention. The cells shall be disposed of properly, including keeping them away from children. Even used cells may cause injury

**WARNINGS**

- **Safety:** Use only with 120V electrical outlets.
- Do not plug into extension cords, power strips, or surge protectors or multioutlet extensions of any type.
- Unit includes tip over protection – this protection will shut the unit off if it tips over to reduce the risk of fire. If unit shuts off due to tip over, unplug the unit and stand it upright, allow to cool for 15 minutes, and plug it back into a 120V wall outlet to reset the unit and begin operation again.
- Unit is equipped with thermal overload protection. If the unit overheats, it will automatically turn off to reduce the risk of fire.
- Unplug the unit before cleaning and moving.
- Never leave the unit unattended when the ceramic heater is operating.
- Place the unit on a hard, level surface when operating. Do not operate the unit on soft or uneven surfaces.
- Do not attempt to take the unit apart.
- Do not block or tamper with the unit when it is turned on. When operating, be sure there are no objects surrounding the unit that could block or restrict the intakes and vents.
- Store in a dry place away from excessive heat and direct sunlight.
- This unit is designed to operate in dry environments only. Do not immerse the unit in water or operate in a damp environment (examples: laundry rooms and bathrooms) or near water.
- **For indoor use only.**
- Do not operate the unit near flammable items or in environments where flammable fumes may be present.
- Do not block the air intakes or exhaust vents. Do not kink the power cord when storing or while in use.
- Do not use this product with any solid-state speed control and do not insert a finger or any object into the vents.
- Do not run the power cord under carpets or rugs.